

All RSI Video Technologies control panel's come equipt with a toggle feature to enable or disable the transmission of events to the Central Station.

With this feature disabled, it can be considered an installation or travel mode. The system will still function normally displaying tampers, arming, disarming but it will not try and transmit the events to the central station. Transmitting tampers during installation can lengthen the install time while waiting to get into programming until the control panel disconnects from the Central Station. Once mounting has been completed and the system is ready to test you are able to flip the setting to enabled and transmit future events.



With the display showing the date and time stamp along with the current Access Level, you must be in Access Level 4

DATE / TIME
DISARMED LVL: 3

Using the RIGHT ARROW go to ACCESS LEVEL and press YES

Using the RIGHT ARROW change the level to 4 and press YES. The display will change to BADGE OR CODE. Enter in the installer code followed by YES

ACCESS LEVEL:
4

The Display will show ACCESS LEVEL 4

Press the RIGHT ARROW until the display shows CONFIGURATION and press YES. The display will change to BADGE OR CODE. Enter the installer code followed by YES.

CONFIGURATION

With the display showing GENERAL PARAMETERS press the LEFT ARROW until the display shows CONFIGURATION MONITOR. STATION and press YES

CONFIGURATION MONITOR.
STATION

The display will show MONITORING PARAMETERS. Press YES

MONITORING PARAMETERS

The display will show MONITORING? DISABLED or ENABLED. Press YES to be able to modify the parameter and the RIGHT ARROW to toggle between enabled and disabled. Press YES when complete.

MONITORING?:
DISABLED

Pressing and holding down the ESC/NO key for 5 seconds will bring you back to the main menu with the date and time stamp.